

Intermediate Service

- Free Visual Safety Report
 - Free Wash and Vac
 - Check all pedal(s) and component(s)
 - Check steering wheel
 - Check horn
 - Check washers
 - Check wipers
 - Check interior lights
 - Check exterior lights
 - Check warning lights
 - Inspect air conditioning filter - replace as necessary*
 - Check seat belts
 - Drain engine oil
 - Replace oil filter
 - Inspect air filters
 - Refill engine oil
 - Check levels and refill as required
 - Inspect suspension
 - Inspect steering
 - Inspect tyres
 - Inspect wheels
 - Check and adjust tyre pressures
 - Inspect brake pads and discs
 - Torque tighten wheel nuts
 - Check radiator and condenser
 - Check belts
 - Check battery
 - Recheck for fluid leaks- underside and engine bay
 - Recheck all levels
 - Reset service lights or monitor as required
 - *Additional charges apply if work is required
-

Full Service

- Free Visual Safety Report
 - Free Wash and Vac
 - Check all pedal(s) and component(s)
 - Check steering wheel
 - Check horn
 - Check washers
 - Check wipers
 - Check interior lights
 - Check exterior lights
 - Check warning lights
 - Inspect air conditioning filter- replace as necessary*
 - Check seat belts
 - Drain engine oil
 - Replace oil filter
 - Inspect air filters
 - Refill engine oil
 - Check levels and refill as required
 - Inspect suspension
 - Inspect steering
 - Inspect tyres
 - Inspect wheels
 - Check and adjust tyre pressures
 - Inspect brake pads and discs
 - Torque tighten wheel nuts
 - Check radiator and condense
 - Check belts
 - Check battery
 - Recheck for fluid leaks - underside and engine bay
 - Recheck all levels
 - Reset service lights or monitor as required
 - Check alarms
-

- Check and adjust gear cables
 - Inspect glass and light lenses
 - Replace battery in locking remote
 - Check and inspect suspension ball free play
 - Replace front and rear differential oils (model dependant)*
 - Inspect drive shaft boots
 - Inspect suspension ball joints and dust covers
 - Inspect fuel and brake pipes
 - Inspect exhaust pipes
 - Inspect wheel bearing
 - Inspect brake lining and drums
 - Inspect hand brake
 - Check clutch fluid as required*
 - Inspect spark plugs
 - Inspect air filter
 - Inspect charcoal canister (model dependant)*
 - Check fuel cap & lines
 - Full 4-wheel alignment check- extra charge for adjustment
 - Change brake fluid (every two years)*
 - Replace air filter (model dependant)
 - Check transmission oil*
 - Inspect transfer box oil (model dependant)*
 - Lubricate prop shaft joints (model dependant)
 - Tighten prop shaft bolts (model dependant)
 - *Additional charges apply if work is required
-